

SPYDER1ATTITUDE

CAT-Bypass Install Instructions

Before You work on your vehicle, make sure it is secured and can't move around while working on it! Wear protective gear!

For this install, same ramps or a lift are recommended.



Required Tools:

- pliers
- wrenches 15 MM, 14 MM, 13 MM, 10 MM
- large screw driver
- ratchet
- sockets 10 MM, 13 MM, 15 MM
- allen wrench 5 MM



Start with removing the muffler. (stock or aftermarket)

For stock you need the 5 MM allen wrench and a 13 MM wrench to remove the screws at the flange. (see picture1)



and the 15 MM socket and 15 MM wrench to loosen bolt at the upper mounting point on the frame



For aftermarket muffler removal you know the steps.

